

HALO SPIN DOCTOR.

FITTING 14MM AXEMEN

Tools required: 2 x 19mm spanner, 5mm hex key.




1: Remove push-fit cones from QR axle (just pull off and keep to one side), then take the nylon faced hammer and tap the axle from the freehub side removing axle and disc side bearing from the hub.



2: Take the M10 axle and install the disc side bearing, washer and 14mm axle stud (this goes on the bulbous end of the axle). Grease first, then tighten with a 19mm spanner.



3: Slide the axle assembly back through the hub from disc side and tap into place with a nylon faced hammer, until the bearing is fully seated.



4: Take drive side washer install this on the axle then take the 14mm axle stud (apply some grease to the threads). Thread this onto the axle and using two 19mm spanners, nip the studs up tight.



5: With everything fitted, check the hub is running free and without any binding. If there is, give the axle a light tap from each side to help center the bearings. After you have done this check that the 14mm axle studs are still tight.

